


- (D) Montageanweisung Elektrischer Ventilantrieb
- (F) Instructions d' Installation Servomoteur de Vanne
- (I) Istruzioni per l' Installazione Attuatore elettrico lineare
- (NL) Installatievoorschrift Lineaire elektrische klepmotor
- (DK) Installationsinstruks Elektrisk linjær ventilmotor
- (N) Installationsinstruktioner Elektrisk ventilmotor
- (FIN) Asennusohje Sähköinen lineaarinen ventiliin toimilaite
- (S) Installations Instruktioner Linjärt ventilställdon
- (E) Instrucciones de montaje Actuador eléctrico lineal

ML6421A,B/ML7421A,B






CENTRA Type A3N/A4N/B3N/B4N

Electric Linear Valve Actuators

INSTALLATION INSTRUCTIONS



<p>A</p>	<p>1</p>	<p>2</p>
<p>3</p>	<p>4</p>	<p>5</p>
<p>6</p>	<p>7</p>	<p>8</p>
		<p>9</p>



Honeywell

Honeywell Regelsysteme GmbH

Honeywellstr. 2-6

D-63477 Maintal

Tel. (0 61 81) 401-1

Fax (0 61 81) 401-400

Subject to change without notice. Printed in Germany

Manufacturing location is certified according to

DIN
EN ISO 9001

EN1C-0130 1298R1-MA